

QCL-based Ammonia Slip Sensor in Thermal Power Plant DeNOx Process

Peng Kang Ph.D., Ting-Jung Lin Ph.D., Yin Wang Ph.D.
Healthy Photon Co., Ltd., Ningbo, Zhejiang, P.R. China
Email: yin.wang@healthyphoton.com Website: www.healthyphoton.com




Introduction

- Ammonia (NH_3) plays a key role in thermal power plant DeNOx process.
 - Excessive NH_3 (ammonia slip) results in higher costs and air pollution.
- Limitations of current NH_3 slip monitor products (NIR laser based):
 - Low resolution & unstability due to high dust and high temperature, etc.
- HealthyPhoton's ultra-sensitive, portable NH_3 analyzer based on MIR QCL spectroscopy:
 - Targeting fundamental transition at $9\mu\text{m}$.
 - Resolution up to $0.01 \text{ ppmv} \cdot \text{m}/\text{Hz}^{1/2}$.
 - Improved system stability and robustness.
 - Possible simultaneous Nitric Oxide (NO) detection with an additional QCL.



Ammonia Slip in DeNOx Process

- NO_x in flue gas emissions from fossil fuel combustion
 - DeNOx process is needed to meet government regulations
- Selective Catalytic Reduction (SCR) process
 - NH_3 slip and NO emission determines process efficiency



Limitations of Current NIR based Products


- Accuracy** lower than required
 NH_3 : 3ppm; NO_x : 25ppm
- In-situ cross-duct spectrometer
Dust: laser beam cannot penetrate
Thermal deformation: beam walk-off




- Extractive spectrometer using multi-pass cell compensating the weak absorption: **system unstable** under severe working conditions (mirror degradation due to salt&dust)

Our Solution: NH_3 +NO Sensor

- Target fundamental transition at $9\mu\text{m}$ -> resolution up to $0.01 \text{ ppmv} \cdot \text{m}/\text{Hz}^{1/2}$
- Simultaneous Nitric Oxide (NO) detection with QCL2 from the same sample




L: Lens; D: Detector;
OAPM: Off-Axis Parabolic Mirror; BS: Beam Splitter



- Hot wet gas sampled from the duct
- Pipe length < 3 meters ensures real-time data
- Getting real-time multi-point concentration


System Performance




Absorption lines selection and 2f demodulation results

- Spectrum at a known concentration was simulated and saved.
- Using least-square fitting of acquired spectrum to retrieve the unknown concentration.


Concentration Step Result



Linearity



Allan Deviation



Real-time concentration distribution of NH_3 (NO)



Precise control of NH_3 injection

Best DeNOx efficiency

Avoid excessive NH_3

Comparison against Axetris' NIR Ammonia Analyzer

- Showing the same trend
- Better accuracy and faster response time



Conclusions and Future Work

- A QCL based NH_3 /NO sensor was developed for DeNOx process monitoring
 - NH_3 : 0.1ppmv/s; (NO: 0.4ppmv/s)
- Compared with traditional NIR sensors:
 - Better accuracy/robustness/reliability in real field condition.
- The system ensures real-time monitoring and optimization for DeNOx process.
- Collaborations with power plants all over China and worldwide.

QCL-based spectrometer modules for the NH_3 /NO sensor prototype, industrial and scientific research applications

QCL/ICL laser



MCT detector



Current/TEC driver



OPEN FOR COLLABORATIONS!

References

- Institute of Clean Air Companies (ICAC). White Paper. Selective Catalytic Reduction (SCR) Control of NO_x Emissions from Fossil Fuel-Fired Electric Power Plants. May 2009.
- United States Environmental Protection Agency. EPA Air Pollution Control Cost Manual. 2016.
- National Energy Administration, China. Electric Power Industry Standard. DL/T 296-2011 The Thermal Power Plant Flue Gas Denitrification Technology Guidelines. 2011.